





GAS GRILL ASSEMBLY GUIDE


310 ORIGINAL • 320 ORIGINAL


LP/NG





58305
























See Owner's Guide for full gas instructions.











Tighten the nuts until snug. Turn only a quarter turn further. DO NOT OVER TIGHTEN.


















See Owner's Guide for the Igniter Module Wire Guide chart.



















WEBER-STEPHEN PRODUCTS LLC www.weber.com

© 2016 Designed and engineered by Weber-Stephen Products LLC, 1415 S. Roselle Road, Palatine, Illinois 60067 USA.